

CAUTIONS FOR EMERGENCY BATTERY USAGE

STORAGE CONDITIONS

1. Temperature range for storage (Humidity: Max. 85%) 0 ~ +35 °C , one year storage
(Storage time will be shortened if out of this temp. range)
2. Storage duration before use: Less than 6 months from batteries received to start with charging.

Note 1: For Ni-Cd battery, we recommend batteries are charged and discharged at least once every 6 months.

Note 2: For Ni-MH battery, we recommend batteries are charged and discharged at least once every 3 months.

Note 3: Never over discharge the battery.

WARNING

- a) Avoid direct soldering onto cells.
- b) Use only within the specified working temperature range.
- c) Do not subject batteries to mechanical shock.

DANGER!

- a) Avoid throwing cells into a fire or attempting to disassemble them. As the electrolyte inside is strong alkaline and can damage skin and clothes.
- b) Avoid short circuiting. It may be leakage.